

the essentials of

Computer Organization and Architecture

Linda Null and Julia Lobur

Chapter 5

A Closer Look at Instruction Set Architectures

Chapter 5 Objectives



- Understand the factors involved in instruction set architecture design.
- Gain familiarity with memory addressing modes.
- Understand the concepts of instruction-level pipelining and its affect upon execution performance.

5.1 Introduction



- This chapter builds upon the ideas in Chapter 4.
- We present a detailed look at different instruction formats, operand types, and memory access methods.
- We will see the interrelation between machine organization and instruction formats.
- This leads to a deeper understanding of computer architecture in general.

5.2 Instruction Formats



Instruction sets are differentiated by the following:

- Number of bits per instruction.
- Stack-based or register-based.
- Number of explicit operands per instruction.
- Operand location.
- Types of operations.
- Type and size of operands.

5.2 Instruction Formats



Instruction set architectures are measured according to:

- Main memory space occupied by a program.
- Instruction complexity.
- Instruction length (in bits).
- Total number of instructions in the instruction set.

5.2 Instruction Formats



In designing an instruction set, consideration is given to:

- Instruction length.
 - Whether short, long, or variable.
- Number of operands.
- Number of addressable registers.
- Memory organization.
 - Whether byte- or word addressable.
- Addressing modes.
 - Choose any or all: direct, indirect or indexed.

5.2 Instruction Formats

- Byte ordering, or *endianness*, is another major architectural consideration.
- If we have a two-byte integer, the integer may be stored so that the least significant byte is followed by the most significant byte or vice versa.
 - In *little endian* machines, the least significant byte is followed by the most significant byte.
 - *Big endian* machines store the most significant byte first (at the lower address).

5.2 Instruction Formats

- As an example, suppose we have the hexadecimal number 12345678.
- The big endian and small endian arrangements of the bytes are shown below.

Address →	00	01	10	11
Big Endian	12	34	56	78
Little Endian	78	56	34	12

5.2 Instruction Formats



- **Big endian:**
 - Is more natural.
 - The sign of the number can be determined by looking at the byte at address offset 0.
 - Strings and integers are stored in the same order.
- **Little endian:**
 - Makes it easier to place values on non-word boundaries.
 - Conversion from a 16-bit integer address to a 32-bit integer address does not require any arithmetic.

5.2 Instruction Formats



- The next consideration for architecture design concerns how the CPU will store data.
- We have three choices:
 1. A stack architecture
 2. An accumulator architecture
 3. A general purpose register architecture.
- In choosing one over the other, the tradeoffs are simplicity (and cost) of hardware design with execution speed and ease of use.

5.2 Instruction Formats

- In a stack architecture, instructions and operands are implicitly taken from the stack.
 - A stack cannot be accessed randomly.
- In an accumulator architecture, one operand of a binary operation is implicitly in the accumulator.
 - One operand is in memory, creating lots of bus traffic.
- In a general purpose register (GPR) architecture, registers can be used instead of memory.
 - Faster than accumulator architecture.
 - Efficient implementation for compilers.
 - Results in longer instructions.

5.2 Instruction Formats

- Most systems today are GPR systems.
- There are three types:
 - Memory-memory where two or three operands may be in memory.
 - Register-memory where at least one operand must be in a register.
 - Load-store where no operands may be in memory.
- The number of operands and the number of available registers has a direct affect on instruction length.

5.2 Instruction Formats

- Stack machines use one - and zero-operand instructions.
- **LOAD** and **STORE** instructions require a single memory address operand.
- Other instructions use operands from the stack implicitly.
- **PUSH** and **POP** operations involve only the stack's top element.
- Binary instructions (e.g., **ADD**, **MULT**) use the top two items on the stack.

5.2 Instruction Formats

- Stack architectures require us to think about arithmetic expressions a little differently.
- We are accustomed to writing expressions using *infix* notation, such as: $Z = X + Y$.
- Stack arithmetic requires that we use *postfix* notation: $Z = XY+$.
 - This is also called *reverse Polish notation*, (somewhat) in honor of its Polish inventor, Jan Lukasiewicz (1878 - 1956).

5.2 Instruction Formats

- The principal advantage of postfix notation is that parentheses are not used.
- For example, the infix expression,

$$Z = (X \times Y) + (W \times U) ,$$

becomes:

$$Z = X Y \times W U \times +$$

in postfix notation.

5.2 Instruction Formats

- In a stack ISA, the postfix expression,

Z = X Y × W U × +

might look like this:

```
PUSH X
PUSH Y
MULT
PUSH W
PUSH U
MULT
ADD
POP Z
```

Note: The result of a binary operation is implicitly stored on the top of the stack!

5.2 Instruction Formats

- In a one-address ISA, like MARIE, the infix expression,

$$Z = X \times Y + W \times U$$

looks like this:

```
LOAD X
MULT Y
STORE TEMP
LOAD W
MULT U
ADD TEMP
STORE Z
```

5.2 Instruction Formats

- In a two-address ISA, (e.g., Intel, Motorola), the infix expression,

$$Z = X \times Y + W \times U$$

might look like this:

```
LOAD R1, X
MULT R1, Y
LOAD R2, W
MULT R2, U
ADD R1, R2
STORE Z, R1
```

Note: One-address ISAs usually require one operand to be a register.

5.2 Instruction Formats

- With a three-address ISA, (e.g., mainframes), the infix expression,

$$Z = X \times Y + W \times U$$

might look like this:

```
MULT R1 , X , Y
MULT R2 , W , U
ADD  Z , R1 , R2
```


Would this program execute faster than the corresponding (longer) program that we saw in the stack-based ISA?

5.2 Instruction Formats

- We have seen how instruction length is affected by the number of operands supported by the ISA.
- In any instruction set, not all instructions require the same number of operands.
- Operations that require no operands, such as **HALT**, necessarily waste some space when fixed-length instructions are used.
- One way to recover some of this space is to use expanding opcodes.

5.2 Instruction Formats

- A system has 16 registers and 4K of memory.
- We need 4 bits to access one of the registers. We also need 12 bits for a memory address.
- If the system is to have 16-bit instructions, we have two choices for our instructions:



5.2 Instruction Formats

- If we allow the length of the opcode to vary, we could create a very rich instruction set:

0000 R1 R2 R3	}	15 3-address codes
1110 R1 R2 R3		
1111 0000 R1 R2	}	14 2-address codes
1111 1101 R1 R2		
1111 1110 0000 R1	}	31 1-address codes
1111 1111 1110 R1		
1111 1111 1111 0000	}	16 0-address codes
1111 1111 1111 1111		

Is there something missing from this instruction set?

5.3 Instruction types



Instructions fall into several broad categories that you should be familiar with:

- Data movement.
- Arithmetic.
- Boolean.
- Bit manipulation.
- I/O.
- Control transfer.
- Special purpose.

Can you think of some examples of each of these?

5.4 Addressing

- Addressing modes specify where an operand is located.
- They can specify a constant, a register, or a memory location.
- The actual location of an operand is its *effective address*.
- Certain addressing modes allow us to determine the address of an operand dynamically.

5.4 Addressing

- *Immediate addressing* is where the data is part of the instruction.
- *Direct addressing* is where the address of the data is given in the instruction.
- *Register addressing* is where the data is located in a register.
- *Indirect addressing* gives the address of the address of the data in the instruction.
- *Register indirect addressing* uses a register to store the address of the address of the data.

5.4 Addressing

- *Indexed addressing* uses a register (implicitly or explicitly) as an offset, which is added to the address in the operand to determine the effective address of the data.
- *Based addressing* is similar except that a base register is used instead of an index register.
- The difference between these two is that an index register holds an offset relative to the address given in the instruction, a base register holds a base address where the address field represents a displacement from this base.

5.4 Addressing

- In *stack addressing* the operand is assumed to be on top of the stack.
- There are many variations to these addressing modes including:
 - Indirect indexed.
 - Base/offset.
 - Self-relative
 - Auto increment - decrement.
- We won't cover these in detail.

Let's look at an example of the principal addressing modes.

5.4 Addressing

- For the instruction shown, what value is loaded into the accumulator for each addressing mode?

Memory

800	900
...	
900	1000
...	
1000	500
...	
1100	600
...	
1600	700

R1 800

LOAD 800

Mode	Value Loaded into AC
Immediate	
Direct	
Indirect	
Indexed	

5.4 Addressing

- These are the values loaded into the accumulator for each addressing mode.

Memory

800	900
...	
900	1000
...	
1000	500
...	
1100	600
...	
1600	700

R1 800

LOAD 800

Mode	Value Loaded into AC
Immediate	800
Direct	900
Indirect	1000
Indexed	700

5.5 Instruction-Level Pipelining



- Some CPUs divide the fetch-decode-execute cycle into smaller steps.
- These smaller steps can often be executed in parallel to increase throughput.
- Such parallel execution is called *instruction-level pipelining*.
- This term is sometimes abbreviated *ILP* in the literature.

The next slide shows an example of instruction-level pipelining.


5.5 Instruction-Level Pipelining



- Suppose a fetch-decode-execute cycle were broken into the following smaller steps:
 1. Fetch instruction.
 2. Decode opcode.
 3. Calculate effective address of operands.
 4. Fetch operands.
 5. Execute instruction.
 6. Store result.
- Suppose we have a six-stage pipeline. S1 fetches the instruction, S2 decodes it, S3 determines the address of the operands, S4 fetches them, S5 executes the instruction, and S6 stores the result.

5.5 Instruction-Level Pipelining

- For every clock cycle, one small step is carried out, and the stages are overlapped.



S1. Fetch instruction.
S2. Decode opcode.
S3. Calculate effective address of operands.

S4. Fetch operands.
S5. Execute.
S6. Store result.

5.5 Instruction-Level Pipelining



- The theoretical speedup offered by a pipeline can be determined as follows:

Let t_p be the time per stage. Each instruction represents a task, T , in the pipeline.

The first task (instruction) requires $k \times t_p$ time to complete in a k -stage pipeline. The remaining $(n - 1)$ tasks emerge from the pipeline one per cycle. So the total time to complete the remaining tasks is $(n - 1)t_p$.

Thus, to complete n tasks using a k -stage pipeline requires:

$$(k \times t_p) + (n - 1)t_p = (k + n - 1)t_p.$$

5.5 Instruction-Level Pipelining



- If we take the time required to complete n tasks without a pipeline and divide it by the time it takes to complete n tasks using a pipeline, we find:

$$\text{Speedup } S = \frac{nt_n}{(k + n - 1)t_p}$$

- If we take the limit as n approaches infinity, $(k + n - 1)$ approaches n , which results in a theoretical speedup of:

$$\text{Speedup } S = \frac{kt_p}{t_p} = k$$

5.5 Instruction-Level Pipelining



- Our neat equations take a number of things for granted.
- First, we have to assume that the architecture supports fetching instructions and data in parallel.
- Second, we assume that the pipeline can be kept filled at all times. This is not always the case. Pipeline *hazards* arise that cause pipeline conflicts and stalls.

5.5 Instruction-Level Pipelining



- An instruction pipeline may stall, or be flushed for any of the following reasons:
 - Resource conflicts.
 - Data dependencies.
 - Conditional branching.
- Measures can be taken at the software level as well as at the hardware level to reduce the effects of these hazards, but they cannot be totally eliminated.

Chapter 5 Conclusion



- ISAs are distinguished according to their bits per instruction, number of operands per instruction, operand location and types and sizes of operands.
- Endianness as another major architectural consideration.
- CPU can store store data based on
 1. A stack architecture
 2. An accumulator architecture
 3. A general purpose register architecture.

Chapter 5 Conclusion



- Instructions can be fixed length or variable length.
- To enrich the instruction set for a fixed length instruction set, expanding opcodes can be used.
- The addressing mode of an ISA is also another important factor. We looked at:
 - Immediate
 - Register
 - Indirect
 - Based
 - Direct
 - Register Indirect
 - Indexed
 - Stack

Chapter 5 Conclusion



- A k -stage pipeline can theoretically produce execution speedup of k as compared to a non-pipelined machine.
- Pipeline hazards such as resource conflicts and conditional branching prevents this speedup from being achieved in practice.
- The Intel, MIPS, and JVM architectures provide good examples of the concepts presented in this chapter.

